What about Broadcast Media?

For most of the 20th century, ^o part of the electromagnetic spectrum ^o was dedicated to television signals ^o broadcasting to most of the world. In the later part of the century, ^o copper cables were used ^o to deliver signals to areas

- that were hard to reach with EM signals.
- ° Again, purely for broadcast.

