

# What About PID Control?

Obvious solution — combine lead *and* lag compensation.

We will develop this further in homework and later in the course using **frequency-response design methods** — which are the subject of several lectures, starting with today's.