## Act 2

Consider electrons in a semiconductor, e.g., silicon. In a perfect crystal at T = 0 the valence bands are filled and the conduction bands are empty -> no conduction. Which of the following could be done to make the material conductive?

- a. heat the material
- b. shine light on it
- c. add foreign atoms that change the number of electrons