Example: Reading the KBSR

(Patt ar … re C.3)

read KBSR:
MAR=xFE00,
R.W=read
MIO.EN=1



 © 2018 Steven S. Lumetta. All rights reserved.

Example: Writing the DDR

(Patt ar … re C.3)

write DDR:
MAR=xFE06,
R.W=write
MIO.EN=1



 © 2018 Steven S. Lumetta. All rights reserved.